



















Majuscules Grossbuchstaben Upper case Mayúsculas	Minuscules Kleinbuchstaben Lower case Minúsculas
 (HT-5118)	 HT-5118x1
 (HT-5119)	 HT-5119x1
 (HT-5120)	 HT-5120x1
 (HT-5121)	 HT-5121x1
 (HT-5122)	 HT-5122x1
 (HT-5123)	 HT-5123x1
 (HT-5124)	 HT-5124x1
 (HT-5125)	 HT-5125x1




Printed in Switzerland


■ Préciser le N° du clavier
Die Tastatur-Nr. angeben
State the keyboard number
Indicar el núm. del teclado


+ Préciser l'écriture
+ Schrift angeben
+ State style of type
+ Indicar la escritura

■ Voir catalogue
Siehe Katalog
See catalogue
Véase catálogo











236
VARIABLE
PROPORTIONEL







1

2

3



238
VARIABLE
PROPORTIONNEL




1

2


3

HERMES ELECTRIC-VARIA


1



2



3



239
VARIABLE
PROPORTIONEL

Printed in Switzerland

Préciser la couleur
Farbe angeben
State colour
Indicar el color